



Grind Assist Table



For Pressure Grinding — — —
Adaptable to Existing Equipment
or - Available With New
G+P Grinders

For Use With Abrasive Belts Only
Do Not Use With Grinding Wheels
Using With Grinding Wheels May Result In Serious Injury



Before




After

STANDARD SPECIFICATIONS

- 3¼ Bore x 9" stroke air cylinder for up and down movement.
- 2" Bore x 3" stroke air cylinder for in and out movement.
- Adjustable infeed stop with lock for grind depth control.
- Air control panel with manual valves, regulators and gages. Panel can be mounted on either side.
- Adjustable stop on table height for in and out plunge grinding.
- Tee-slotted table top (not shown)

OPTIONS

- Hydro-check
- Air Logic controls



Always wear eye protection when grinding.
Be sure all guards are in place.